

Regatta Pro-Start Instructions

Pre-Race Preparation:

1. Plug unit into the 12V outlet under the radio. Clip horns to the grab rail on top of the roof. Run the cable through the captain's side window. This saves your ears - the horn is LOUD!
2. Press the **Select Sequence** button once. Listen to the beeps to determine what sequence is currently set.
 - a. Thursday Night: 3 minute rolling dinghy start (App S): three long beeps

- b. Wed Night: 5 minute rolling start (Rule 26): five long beeps

- c. If the starting sequence is not the one you want, press and hold the **Select Sequence** button to cycle through the sequences. Release the button just after you hear the sequence you want.


Sequence	Beeper Order	Sound
	—	1 long
	— —	2 long
App S, 3 Min	— — —	3 long
	— — — •	3 long, 1 short
	— — — — — • • •	5 long, 3 short
Rule 26, 5 min	— — — — —	5 long
	— — — — — •	5 long, 1 short
	— — — — — —	6 long
	— — — — — —	2 long, 2 long
	— — — — — — — —	3 long, 3 long
	— — — — — — — — — —	5 long, 5 long

The Start

1. As needed: use the Manual horn at any time to call attention to racers, over early, AP signals, etc.
2. Press the **Start Sequence** button 1 minute prior to when you want the 5-min or 3-min sequence to begin (ex: Wed night hit the button at 1824 for an 1825 sequence start.)

Note: Pressing the **Start Sequence** button starts the pre-sequence alert/countdown to the start and will automatically move into the start sequence.

3. The starts will roll automatically.
4. After the last start, press the **Select Sequence** and **Options** buttons together in order to stop the rolling/starts [or unplug the horn].



Individual and General Recalls: Use the **Manual Horn** button to sound the horn.

Testing: Want to test the sequence settings prior to the race without blowing your ears out? Plug the two horns with paper towels and press **Start Sequence**. The horns are air horns, so depriving them of air will allow you to hear the horn 'clicks' without a loud noise.

End of night: Store the horn in the canvas bag to minimize corrosion/moisture build up.

DO NOT REMOVE HORN FROM RC BOAT!